


SMALL SIZE ROLLING SHUTTER DOOR REMOTE CONTROL PANEL




230V



ROL-400-A



The ONLY adjustment necessary for the circuit board is to enter the code.



INSTALLATION INSTRUCTIONS - ENTERING THE CODE

Connect the circuit board as shown in the figure above.

To enter (or to change) the code follow the steps described below:

1. Open the remote and enter a code.
2. Press the only button that is on the circuit board, (LEARN CODE) and press one of the buttons on the remote simultaneously. The board will only store one code, thus, each time a new one is entered the previous one is cleared.

The operating time of the motor is about four (4) minutes and it **CANNOT BE ADJUSTED**.

This is essentially the maximum operating time and not the actual time after which the motor stops. There is an electronic circuit on the board which "senses" when the motor has stopped through its own limit switch and deactivates the command relay.

CAUTION ! : It is precisely because of this electronic circuit that the device will not function unless a motor is connected.

An "UP - DOWN" version is also available: using the left button of the remote the door will move in one direction and with the right button in the opposite one. To stop it in between, press any of the two buttons.